



INSTALLATION INSTRUCTIONS:

- 1.0 INSTALL (2) RIVNUTS (ITEM #15) INTO FRAME. MOUNT RELAY BOX (ITEM #50) USING (2) SCREWS (ITEM #10).
- 2.0 REMOVE LOWER RIGHT CONTROL BOX MOUNTING SCREW AND ADD LIGHT ASSEMBLY (FROM 76-00520 KIT), RE-INSTALL MOUNTING SCREW.
- 3.0 REFER TO WIRING DIAGRAM AND CONNECT BOX BY THE FOLLOWING INSTRUCTIONS
  - 3.1 REMOVE AND DISCARD JUMPER (J1-J1) FROM ENGINE HARNESS. PLUG IN CONNECTOR FROM SHUTDOWN OPTION BOX.
  - 3.2 CONNECT GROUND HARNESS FROM SHUTDOWN BOX TO LOW FUEL CONNECTOR ON ENGINE HARNESS.

VOID

PART NUMBER	DESCRIPTION
98-02393-00	LOW FUEL SHUTDOWN
98-02393-01	LOW FUEL / DOOR SWITCH
98-02393-02	DOOR SWITCH
98-02393-03	LOW FUEL SHUTDOWN (ETO)
98-02393-04	LOW FUEL / DOOR SWITCH (ETO)

SYM	REVISION RECORD	DATE	BY	CHK'D	APP'D	AUTH NO.
B	VOID AND SUPERSEDED BY 98-03251.	30AUG2005	ZMG			72N223GP05
A	CHANGED CONNECTION DESIGNATORS TO REFLECT NDL PRODUCTS.	5/18/04	PJS			72N013GP04
-	INITIAL RELEASE.	10/11/01	PJS			72N023GP00

SUPERSEDES

TITLE

INSTALLATION INSTRUCTIONS

DRAWING NO.

98-02393

REV

SHEET 1 of 1

B